

Werks

COMPOSITES

997 Turbo Carbon Fiber Front Splitter Installation Instructions



Supplied Hardware:



Installation Instructions:

- Remove bolts holding the stock front airdam in place
- Remove the stock airdam by pull out and down to release the plastic clips
- Install the splitter by starting at one end and work the part into the seam along the front of the car
- Secure using the supplied spacers and bolts



- Make a small cut in the rubber wheel flap as shown below

